COOKER\$ REWORK BULLETIN

DATE:21.06.2018

PAGE : 1/2

1. Tilt the oven to a soft place (for example above a sytrofoam).



2. Disassemble the screws which are shown in the circles below and take out the adjustable feets.



COOKER\$ REWORK BULLETIN

ITEM NR:		
PAGE	: 2/2	

3. Thereafter assemble the adjustable feets into the plinths.



4. Assemble the screws as shown below.

